


























Zestawienie uchwytów

Model uchwytu	Zdjęcie uchwytu	Kamera lub uchwyt	Zdjęcie obudowy kamery/uchwytu
TC-P54BM V5		TC-C32WP, TC-C32HN, TC-C32XP, TC-C34WS, TC-C34XS, TC-C34UP, TC-C35XS, TC-C35WS, TC-C35HS, TC-C35US, TC-C38XS, TC-C38WS, TC-NH-A36	
TC-NC-A29		TC-C32HN, TC-C32XP, TC-C34XS, TC-C35XS, TC-C35HS, TC-C35KS V2, TC-C38HS, TC-C38XS	
TC-NH-A35		TC-C32WP, TC-C34WS, TC-C35WS, TC-C38WS, TC-P54BM V5, TC-NH-A22	
TC-NH-A36		TC-C32WP, TC-C32HN, TC-C32XP, TC-C34XS, TC-C35XS, TC-C35HS, TC-C38XS, TC-P54BM V5, TC-NC-A22, TC-NC-811	
TC-NC-A22		TC-C34SP, TC-C34GN, TC-C35SS, TC-C35KS V2, TC-C35JS, TC-C35LQ, TC-C38SS, TC-C38LS, TC-C38JS, TC-NH-A35, TC-NH-A36	
TC-NC-A28		TC-C34SP, TC-C35SS, TC-C35MS, TC-C38SS	
TC-NC-A20		TC-NC-A21	
TC-NC-A21		TC-C34SP, TC-C35SS, TC-C35KS, TC-C38SS	
TC-NC-A25		TC-NC-A21, TC-NH-A35, TC-NH-A36, TC-NC-811	
TC-NC-A27		TC-NC-A21, TC-NH-A35, TC-NH-A36, TC-NC-811	
TC-NC-811		TC-NC-A25, TC-NC-A27	
TC-A37		TC-H324, TC-H326, TC-H356	
TC-A38		TC-A37	