




























Model uchwyty	Zdjęciu uchwyty	Kamera lub uchwyt	Zdjęcie obudowy kamery/uchwyty
TC-P54BM V5		TC-C32WP; TC-C32HN; TC-C32XP; TC-C34WS; TC-C34XS; TC-C34UP; TC-C35XS; TC-C35WS; TC-C35HS; TC-C35US; TC-C38XS; TC-C38WS; TC-NH-A36	
TC-NC-A29		TC-C32HN; TC-C32XP; TC-C34XS; TC-C35XS; TC-C35GS; TC-C35KS V2; TC-C38HS; TC- C38XS	
TC-NC-A35		TC-C32WP; TC-C34WS; TC-C35WS; TC- C38WS; TC-P54BM V5; TC-NH-A22	
TC-NC-A36		TC-C32WP; TC-C32HN; TC-C32XP; TC-C34XS; TC-C35XS; TC-C35HS; TC-C38XS; TC-P54BM V5; TC-NH-A22; TC-NH-811	
TC-NC-A22		TC-C34SP; TC-C34GN; TC-C35SS; TC-C35KS V2; TC-C35JS; TC-C35LQ; TC-C38SS; TC- C38LS; TC-C38JS; TC-NH-A35; TC-NH-A36	
TC-NC-A28		TC-C34SP; TC-C35S; TC-C35MS; TC-C38SS	
TC-NC-A20		TC-NH-A23; TC-NH-A24	
TC-NC-A21		TC-NC-A23; TC-NC-A24	
TC-NC-A23		TC-C32HN; TC-C32XP; TC-C34XS; TC-C35XS; TC-C35HS; TC-C35KS V2; TC-C38HS; TC- C38XS	
TC-NC-A24		TC-C34SP; TC-C35SS; TC-C35KS; TC-C38SS	
TC-NC-A25		TC-C32HN; TC-C32XP; TC-C34XS; TC-C35XS; TC-C35HS; TC-C35KS V2; TC-C38HS; TC- C38XS	
TC-NC-A27		TC-C34SP; TC-C35SS; TC-C35KS; TC-C38SS	
TC-NC-811		TC-NC-A25; TC-NC-A27	
TC-NC-A37		TC-H324; TC-H326; TC-H356	
TC-NC-A38		TC-A37	